TwistFlyer™

PULL-STRING FLYER · BY MIRTHSTEAD CREATIONS

QUICK START

How to Fly

5+ AGES



White side up

1 Load the TwistStrip™

Slide the strip through the launcher so its teeth mesh with the gear. It only fits one way. Push it in until the ring stops at the handle.

2 Seat a rotor

Press a rotor firmly onto the gear spindle with the **white side facing up**. It should sit flat and level.

3 Aim up and away — outdoors

Hold the handle level and point it up, away from faces, people and pets. Fly outdoors in a big open space. **Not for indoor use.**

4 Pull and soar

Grip the ring and pull the strip all the way out in **one quick, smooth motion**. Keep a firm grip on the handle and watch it climb.

FLY HIGHER: a fast, full-length pull beats a hard, short one. Reload the strip each time and keep your launch hand steady.

✓ **Hand-inspected & flight-tested**
Every part, before it ships

INSPECTED BY _____ DATE _____ BATCH / LOT _____

TwistFlyer™

PULL-STRING FLYER · BY MIRTHSTEAD CREATIONS

QUICK START

How to Fly

5+ AGES



White side up

1 Load the TwistStrip™

Slide the strip through the launcher so its teeth mesh with the gear. It only fits one way. Push it in until the ring stops at the handle.

2 Seat a rotor

Press a rotor firmly onto the gear spindle with the **white side facing up**. It should sit flat and level.

3 Aim up and away — outdoors

Hold the handle level and point it up, away from faces, people and pets. Fly outdoors in a big open space. **Not for indoor use.**

4 Pull and soar

Grip the ring and pull the strip all the way out in **one quick, smooth motion**. Keep a firm grip on the handle and watch it climb.

FLY HIGHER: a fast, full-length pull beats a hard, short one. Reload the strip each time and keep your launch hand steady.

✓ **Hand-inspected & flight-tested**
Every part, before it ships

INSPECTED BY _____ DATE _____ BATCH / LOT _____

Pull. Spin. Soar. Turn over for safety, side effects, troubleshooting and the spare gear.

Made in St. Louis, MO · twistflyer.com · info@twistflyer.com

TwistFlyer™

PULL-STRING FLYER · BY MIRTHSTEAD CREATIONS

KEEP THIS CARD

Fly Safe & Fix It

5+ AGES

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 yrs. Adult supervision recommended. Even though PETG is safe, **never put any part in your mouth.** If a child swallows a part, get medical help right away; **if a pet swallows a part, seek immediate veterinary attention.** Fly outdoors in a large open space, away from power lines, trees and roads. Never launch toward faces, people or animals, and keep your face clear of the rotor at launch. Do not try to catch a spinning rotor. **Not for indoor use** – rotors leave the launcher at high speed and can break against walls and ceilings. Inspect rotors before each flight; replace any that are cracked or bent. **Never climb trees, ladders or roofs, or run into a street, to retrieve a rotor** – ask an adult. Use is subject to the terms at twistflyer.com/policies.

TROUBLESHOOTING

- **Won't climb?** White side up, then pull faster and all the way out.
- **Strip won't go in?** Flip it over. Teeth face the gear.
- **Rotor wobbles?** Press it fully down. Replace a bent rotor.
- **Pull feels rough?** A drop of silicone grease on the gear and strip teeth.
- **Gear slips or clicks?** Swap in the spare gear.
- **Glow fading?** Charge glow rotors under bright light or sun for a few minutes.

CARE

Store flat, out of hot cars and direct sun; heat can warp PETG. Clean with a damp cloth. Don't bend the blades. Use silicone grease only, not oil.

SWAP THE SPARE GEAR



1. Pull out the TwistStrip™ and remove the rotor.
2. Unscrew the white cap and lift out the gear assembly.
3. Drop in the spare, gear first, then screw the cap back on hand-tight.

Possible side effects

Not medical advice. Very much TwistFlyer advice.

- Spending a lot more time outdoors.
- Long stretches away from phones, tablets and screens.
- Adults hiding a second set from the kids. (Hence the Family Set.)
- Rotors in trees, gutters and roofs – and new friends among the neighbors who bring them back.
- Mild neck strain from looking up.
- Sudden "who can go highest" contests and loud bragging.
- Glow rotors stretching bedtime to "just one more flight."
- Laughter, fresh air, grass stains and dogs with strong opinions.

Keep the fleet flying

3-Rotor Sets · Glow-in-the-Dark Rotors · Replacement TwistStrip™ · Replacement Gear · Custom colors

Order at twistflyer.com · orders@twistflyer.com

© 2026 Mirthstead Creations LLC. TwistFlyer™ and TwistStrip™ are trademarks of Mirthstead Creations LLC.

Made in St. Louis, MO · twistflyer.com/instructions

TwistFlyer™
PULL-STRING FLYER · BY MIRTHSTEAD CREATIONS
KEEP THIS CARD
Fly Safe & Fix It
5+ AGES
WARNING: CHOKING HAZARD – Small parts. Not for children under 3 yrs. Adult supervision recommended. Even though PETG is safe, never put any part in your mouth. If a child swallows a part, get medical help right away; if a pet swallows a part, seek immediate veterinary attention. Fly outdoors in a large open space, away from power lines, trees and roads. Never launch toward faces, people or animals, and keep your face clear of the rotor at launch. Do not try to catch a spinning rotor. Not for indoor use – rotors leave the launcher at high speed and can break against walls and ceilings. Inspect rotors before each flight; replace any that are cracked or bent. Never climb trees, ladders or roofs, or run into a street, to retrieve a rotor – ask an adult. Use is subject to the terms at twistflyer.com/policies.
TROUBLESHOOTING
Won't climb? White side up, then pull faster and all the way out.
Strip won't go in? Flip it over. Teeth face the gear.
Rotor wobbles? Press it fully down. Replace a bent rotor.
Pull feels rough? A drop of silicone grease on the gear and strip teeth.
Gear slips or clicks? Swap in the spare gear.
Glow fading? Charge glow rotors under bright light or sun for a few minutes.
CARE
Store flat, out of hot cars and direct sun; heat can warp PETG. Clean with a damp cloth. Don't bend the blades. Use silicone grease only, not oil.
SWAP THE SPARE GEAR



1. Pull out the TwistStrip™ and remove the rotor.
2. Unscrew the white cap and lift out the gear assembly.
3. Drop in the spare, gear first, then screw the cap back on hand-tight.
Possible side effects
Not medical advice. Very much TwistFlyer advice.
Spending a lot more time outdoors.
Long stretches away from phones, tablets and screens.
Adults hiding a second set from the kids. (Hence the Family Set.)
Rotors in trees, gutters and roofs – and new friends among the neighbors who bring them back.
Mild neck strain from looking up.
Sudden "who can go highest" contests and loud bragging.
Glow rotors stretching bedtime to "just one more flight."
Laughter, fresh air, grass stains and dogs with strong opinions.
Keep the fleet flying
3-Rotor Sets · Glow-in-the-Dark Rotors · Replacement TwistStrip™ · Replacement Gear · Custom colors
Order at twistflyer.com · orders@twistflyer.com
© 2026 Mirthstead Creations LLC. TwistFlyer™ and TwistStrip™ are trademarks of Mirthstead Creations LLC.
Made in St. Louis, MO · twistflyer.com/instructions